


VR240

Dimensional drawing (Right version)



Connections

1. Outdoor air
2. Supply air
3. Extract air
4. Discharge air

- A. Gable location
- B. Top location
- C. Rear location