VR480

Dimensional drawing (Right version)



Connections

1. Outdoor air
2. Supply air
3. Extract air
4. Discharge air

A. Gable location
B. Top location
C. Rear location

Nilan A/S
www.en.nilan.dk • nilan@nilan.dk